


**SERVICE PARTS LIST**

**THE M.G. Series MGA 1500**

Item No.	DESCRIPTION	Commencing (C) 10101		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	<b>EXHAUST SYSTEM</b>										
1	Exhaust pipe assembly	ARH63	AH1	1	1						
2	Pipe—front	ARH1053	AH2	1	1						
3	Silencer and tail pipe	ARH65	AH3	1	1						
4	Packing—exhaust pipe	AHH5146	AH4	1	1						
5	<b>Mounting—exhaust—intermediate</b>	<b>AHH5402</b>	<b>AH5</b>	<b>1</b>	<b>1</b>						
6	Bush for intermediate exhaust mounting	AHH5403	AH6	2	2						
7	Housing—intermediate exhaust mounting	AHH5404	AH7	1	1						
8	Bolt—bush and housing to pipe	HBZ0522	AH8	1	1						
9	Nut—bush and housing bolt	FNZ105	AH9	1	1						
10	Washer for bolt (spring)	LWZ205	AH10	1	1	24					
11	<b>Mounting—exhaust—rear</b>	<b>AHH5405</b>	<b>AH11</b>	<b>1</b>	<b>1</b>						
12	Screw—mountings to frame	HZS0404	AH12	4	4						
13	Nut for screw	FNZ104	AH13	4	4						
14	Washer for screw (spring)	LWZ204	AH14	4	4						
15	Bolt—rear mounting and tail pipe	HBZ0422	AH15	1	1						
16	Nut for rear mounting bolt	FNZ104	AH16	1	1						
17	Washer for bolt (spring)	LWZ204	AH17	1	1						
18	Washer for bolt (plain)	PWZ104	AH18	2	2	12					
19	Screw—housing to intermediate mounting	HZS0404	AH19	2	2						
20	Nut for housing screw	FNZ104	AH20	2	2						
21	Washer for screw (spring)	LWZ204	AH21	2	2						
22	Strap—upper front mounting	AHH5406	AH22	1	1						
23	Strap—lower front mounting	AHH5407	AH23	1	1						
24	Screw—strap to front pipe	HZS0505	AH24	1	1						
25	Nut for strap screw	FNZ105	AH25	1	1						
26	Washer for strap screw (spring)	LWZ205	AH26	1	1	24					
27	Washer for strap screw (plain)	PWZ105	AH27	1	1						



A2126