



SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	EXHAUST SYSTEM										
1	Exhaust pipe assembly	ARH103	AL1	1	1						
2	Flange	AHH5145	AL2	2	2						
3	Intermediate pipe and silencer assembly	ARH104	AL3	1	1						
4	Intermediate pipe assembly	ARH1229	AL4	1	1						
5	Packing—exhaust pipe	AHH5146	AL5	2	2						
6	Mounting—exhaust—intermediate	AHH5402	AL6	1	1						
7	Bush—intermediate exhaust mounting	AHH5403	AL7	2	2						
8	Housing—intermediate exhaust mounting	AHH5404	AL8	1	1						
9	Bolt—bush and housing to pipe	HBZ0522	AL9	1	1						
10	Nut for bolt	FNZ105	AL10	1	1						
11	Washer for bolt (spring)	LWZ205	AL11	1	1	24					
12	Mounting—exhaust (rear)	AHH5819	AL12	1	1						
13	Screw—mountings to frame	HZS0404	AL13	4	4						
14	Nut for screw	FNZ104	AL14	4	4						
15	Washer for screw (spring)	LWZ204	AL15	4	4	12					
16	Bolt—rear mounting and tail pipe	HBZ0422	AL16	1	1						
17	Nut for bolt	FNZ104	AL17	1	1						
18	Washer for bolt (spring)	LWZ204	AL18	1	1						
19	Washer for bolt (plain)	PWZ104	AL19	2	2						
20	Screw—housing to intermediate mounting	HZS0404	AL20	2	2						
21	Nut for screw	FNZ104	AL21	2	2						
22	Washer for screw (spring)	LWZ204	AL22	2	2	12					
23	Strap—upper front mounting	AHH5406	AL23	1	1						
24	Strap—lower front mounting	AHH5407	AL24	1	1						
25	Screw—strap to front pipe	HZS0505	AL25	1	1						
26	Nut for screw	FNZ105	AL26	1	1						
27	Washer for screw (spring)	LWZ205	AL27	1	1	24					
28	Washer for screw (plain)	PWZ105	AL28	1	1						
29	Clip for connecting pipe	AHH5818	AL29	1	1						
30	Screw for clip	HZS0508	AL30	1	1						
31	Nut for screw	FNZ105	AL31	1	1						
32	Washer for screw (spring)	LWZ205	AL32	1	1	24					